

CITROEN			ant/front		post/rear
2 CV					
0.6 Charleston	4/81-4/89	CT	0058	CT	Drums
0.6 Special E	4/81-10/90	CT	0195	CT	Drums
AX					
1.0	9/86-4/97	CT	0274	BE	Drums
1.1	86-4/97	CT	0274	BE	Drums
1.3	3/87-4/97	CT	0274	BE	Drums
1.4	86-8/89	CT	0274	BE	Drums
1.4	7/91-4/97	BE	0207	BE	Drums
1.4 Diesel RD-TRD-TGD	9/88-4/97	CT	0274	BE	Drums
1.4 Diesel TD	7/91-4/97	BE	0207	BE	Drums
1.4 GT	88-8/89	CT	0274	BE	Drums
1.4 GT	7/91-4/97	CT	0274	BE	Drums
1.4 GT	7/91-4/97	BE	0207	BE	Drums
1.4 GTI	9/89-4/97	CT	0274	BE	Drums
1.4 TRS	9/89-4/97	CT	0274	BE	Drums
1.4 TZS	7/91-4/97	CT	0274	BE	Drums
BX					
1.4	9/82-4/94	BE	0184	CT	0161
1.6	9/82-4/94	BE	0184	CT	0161
1.9	10/83-4/94	BE	0184	CT	0161
1.9 Diesel	10/83-4/94	BE	0184	CT	0161
CX					
2.0	74-8/77	CT	0086	CT	0087
2.0	77-8/79	CT	0086	CT	0161
2.0	79-7/82	CT	0086	CT	0161
2.0 Break	75-8/79	CT	0086	CT	T.B.A.
2.0 Break	79-5/90	CT	0086	CT	T.B.A.
2.0	82-8/85	CT	0086	CT	0161
2.0	79-5/90	CT	0086	CT	0161
2.0 Break	82-8/85	CT	0086	CT	T.B.A.
2.0 Break	85-5/90	CT	0086	CT	T.B.A.
2.0 Break	89-5/90	CT	0086	CT	T.B.A.
2.2	74-8/76	CT	0086	CT	0087
2.2 Break	75-8/76	CT	0086	CT	T.B.A.
2.2 Break Diesel	75-8/78	CT	0086	CT	T.B.A.
2.2 Diesel	75-8/77	CT	0086	CT	0087
2.2 Diesel	77-8/78	CT	0086	CT	0161
2.2 Diesel	75-8/78	CT	0086	CT	T.B.A.
2.2	85-5/90	CT	0086	CT	0161
2.2	85-5/90	CT	0086	CT	T.B.A.
2.2	85-5/90	CT	0086	CT	0161
2.4	76-8/77	CT	0086	CT	0087
2.4	77-8/79	CT	0086	CT	0161
2.4 C-Matic	75-5/90	CT	0086	CT	0161
2.4	75-8/77	CT	0086	CT	0087
2.4	77-5/90	CT	0086	CT	0161
2.4 Break	76-5/82	CT	0086	CT	T.B.A.
2.4 GTi	77-6/81	CT	0086	CT	0161
2.5 Diesel	78-7/82	CT	0086	CT	0161

2.5 Diesel	81-9/83	CT	0086	CT	0161
2.5 Diesel	78-7/82	CT	0086	CT	0161
2.5 Diesel	77-5/81	CT	0086	CT	0161
2.5 Diesel	78-7/82	CT	0086	CT	0161
2.5 Diesel Break	78-7/82	CT	0086	CT	T.B.A.
2.5 Break	77-5/81	CT	0086	CT	T.B.A.
2.5 Break	77-5/81	CT	0086	CT	T.B.A.
2.5 Break	81-9/83	CT	0086	CT	T.B.A.
2.5 Diesel	82-8/85	CT	0086	CT	0161
2.5 Diesel	85-5/90	CT	0086	CT	0161
2.5 Diesel Break	78-5/90	CT	0086	CT	T.B.A.
2.5 Diesel Break	85-5/90	CT	0086	CT	T.B.A.
2.5 Turbodiesel Break	87-5/90	CT	0086	CT	T.B.A.
2.5	81-5/89	CT	0086	CT	T.B.A.
2.5	85-5/90	CT	0086	CT	0161
2.5 Turbo Break	81-5/90	CT	0086	CT	T.B.A.
2.5 Turbo Break	81-5/90	CT	0086	CT	T.B.A.
2.5 Turbodiesel	85-5/90	CT	0086	CT	0161
2.5 Turbo	85-5/90	CT	0086	CT	0161
2.5 Turbo	85-5/90	CT	0086	CT	0161
2.5 GTi	83-5/90	CT	0086	CT	0161
2.5 Turbo GTi	85-5/90	CT	0086	CT	0161
2.5 iE	81-1/87	CT	0086	CT	0161
2.5 Break	83-5/90	CT	0086	CT	T.B.A.
C1					
1.0	6/05-	BO	1406	BO	Drums
1.4 HDi	6/05-	BO	1406	BO	Drums
C2					
1.1	9/03-	LU	0304	LU	Drums
1.4 HDi	9/03-	LU	0304	LU	Drums
1.6 VTR	9/03-	LU	0308	LU	0305
1.6 VTR-VTS	1/05-	BO	0308	LU	0305
C3					
1.1	2/02-	LU	0304	LU	Drums
1.4	2/02-	LU	0304	LU	Drums
1.6 16v	2/02-	LU	0308	LU	0305
C4					
1.4	10/04-	BO	0309	BO	1443
1.4 (EDS)	10/04-	BO	1472	BO	1443
1.6	10/04-	BO	0309	BO	1443
1.6 (EDS)	10/04-	BO	1472	BO	1443
1.6 HDi	10/04-	BO	0309	BO	1443
1.6 HDi (EDS)	10/04-	BO	1472	BO	1443
2.0	10/04-	BO	1472	BO	1443
2.0 VTS	10/04-	AT	0471P	BO	1443
2.0 HDi	10/04-	AT	0471P	BO	1443
C5					
1.8 16V	3/01-	BO	1482	CT	T.B.A.
2.0 16V	3/01-	BO	1486	CT	T.B.A.
2.0 Hdi	3/01-	BO	1486	CT	T.B.A.
2.2 16V HDi	3/01-	BO	1483	CT	T.B.A.

3.0 V6 24V	3/01-	BO	1483	CT	T.B.A.
<b>C6</b>					
2.7 HDi	9/05-	LU	T.B.A.	LU	T.B.A.
3.0 V6	9/05-	LU	T.B.A.	LU	T.B.A.
<b>C8</b>					
2.0	7/02-	LU	0329	LU	0305
2.2	7/02-	LU	0329	LU	0305
3.3	7/02-	LU	0329	LU	0305
<b>Dyane</b>					
0.6	77-6/84	CT	0058	CT	Drums
0.6 Confort	79-6/84	CT	0195	CT	Drums
<b>Evasion</b>					
1.8	2/96-7/02	BE	6746	BE	Drums
1.9 Turbo D	6/94-7/02	LU	0738	BE	Drums
1.9 Turbo D (ABS)	6/94-7/02	LU	0738	AT	0299
2.0	6/94-7/02	LU	0738	BE	Drums
2.0 (ABS)	6/94-7/02	LU	0738	AT	0299
2.0 Turbo CT	6/94-7/02	LU	0738	AT	0299
2.1 Turbo D	6/96-7/02	LU	0738	BE	Drums
2.1 Turbo D (ABS)	6/96-7/02	LU	0738	AT	0299
<b>Saxo</b>					
1.0	2/96-	AT	0274	BE	Drums
1.1	2/96-	BE	0207	BE	Drums
1.4	2/96-	BE	0207	BE	Drums
1.5 Diesel	2/96-	BE	0207	BE	Drums
1.6	2/96-	AT	0223	BE	0227
1.6 VTR	2/96-	AT	0223	BE	0227
1.6 VTS	2/96-	AT	0223	BE	0227
<b>Synergie</b>					
1.8	5/97-7/02	BE	6746	BE	Drums
1.8 (ABS)	6/94-7/02	LU	0738	AT	0299
1.9 TD	6/94-7/02	LU	0738	BE	Drums
1.9 TD (ABS)	6/94-7/02	LU	0738	AT	0299
2.0	6/94-7/02	LU	0738	BE	Drums
2.0 (ABS)	6/94-7/02	LU	0738	AT	0299
<b>Visa</b>					
0.7 Club - Special	9/78-8/80	BE	0070	BE	Drums
0.7 Club - Special	9/78-8/80	BE	0070	LU	Drums
0.7 L	6/81-2/86	CT	0152	BE	Drums
0.7 Super	9/78-8/80	BE	0070	BE	Drums
0.7 Super	9/78-8/89	BE	0070	LU	Drums
0.7 Club-Special	9/80-9/88	CT	0152	BE	Drums
0.7 Club-Special	9/80-9/88	CT	0152	LU	Drums
1.1 E - RE	8/83-9/88	CT	0152	BE	Drums
1.1 E - RE	8/83-9/88	CT	0152	LU	Drums
1.1 Super E	9/80-7/84	CT	0152	LU	Drums
1.1 Super X	9/80-9/85	CT	0152	BE	Drums
1.4	4/81-9/85	LU	0250	BE	Drums
1.4	4/81-9/85	AT	0083A	LU	Drums
1.4 Cabriolet	4/81-9/85	CT	0152	BE	Drums
1.4 GT	4/81-9/85	CT	0152	BE	Drums

1.4 GT	4/81-9/85	CT	0152	LU	Drums
1.4 TRS	7/84-1/88	AT	0083A	BE	Drums
1.4 TRS	7/84-1/88	AT	0083A	LU	Drums
1.6 GTi	7/84-1/88	LU	0250	BE	Drums
1.6 GTi	7/84-1/88	LU	0250	LU	Drums
1.7 Diesel	4/84-10/89	BE	0184	BE	Drums
1.7 Diesel	4/84-10/89	LU	0250	LU	Drums
<b>Xantia</b>					
1.6	3/93-12/97	BE	6005	CT	6002
1.8	3/93-3/01	BE	6005	CT	6002
1.8 Break	3/93-3/01	BE	6005	CT	T.B.A.
1.9 D	3/93-8/96	BE	6005	CT	6002
1.9 SD	9/96-3/01	BE	6005	CT	6002
1.9 SD Break	9/96-3/01	BE	6007	CT	T.B.A.
1.9 TD	3/93-3/01	BE	6007	CT	6002
1.9 TD Break	7/95-3/01	BE	6007	CT	T.B.A.
1.9 TD	3/98-3/01	BO	T.B.A.	CT	6002
1.9 TD Break	3/98-3/01	BO	T.B.A.	CT	T.B.A.
2.0	3/93-2/98	BE	6005	CT	6002
2.0	3/98-3/01	BE	6007	CT	6002
2.0 Break	7/95-3/01	BE	6007	CT	T.B.A.
2.0	6/95-8/99	BE	6003	CT	6002
2.0 Break	7/95-3/01	BE	6003	CT	T.B.A.
2.0	7/98-3/01	BO	T.B.A.	CT	6002
2.0 Break	7/98-3/01	BO	T.B.A.	CT	T.B.A.
2.1 TD	6/95-8/99	BE	6003	CT	6002
2.1 TD Break	6/95-8/99	BE	6003	CT	T.B.A.
2.1 TD	9/99-3/01	BO	T.B.A.	CT	6002
2.1 TD Break	9/99-3/01	BO	T.B.A.	CT	T.B.A.
3.0	11/96-3/01	BO	T.B.A.	CT	6002
3.0 Break	1/98-3/01	BO	T.B.A.	CT	T.B.A.
<b>XM</b>					
2.0	10/89-3/91	BE	6001	CT	6002
2.0	4/91-5/94	BE	6003	CT	6002
2.0i	10/89-3/91	BE	6001	CT	6002
2.0i	4/91-5/94	BE	6003	CT	6002
2.0i Break	4/91-5/94	BE	6003	CT	T.B.A.
2.1 Diesel - Turbo Diesel	10/89-3/91	BE	6001	CT	6002
2.1 Diesel - Turbo Diesel	4/91-5/94	BE	6003	CT	6002
2.5 Turbo Diesel	10/89-4/97	BE	6003	CT	6002
2.5 Turbo Diesel	5/97-2/01	BO	T.B.A.	CT	6002
2.5 Turbo Diesel Break	10/89-4/97	BE	6003	CT	T.B.A.
2.5 Turbo Diesel Break	5/97-2/01	BO	T.B.A.	CT	T.B.A.
3.0 V6	10/89-3/91	BE	6001	CT	6002
3.0 V6	10/89-3/91	AT	0298	CT	6002
3.0 V6	4/91-5/94	BE	6003	CT	6002
3.0 V6 Break	4/91-5/94	BE	6003	CT	T.B.A.
3.0 V6	5/97-2/01	BO	T.B.A.	CT	6002
<b>Xsara</b>					
1.4	7/97-8/00	BO	0209	LU	Drums
1.4	7/97-8/00	BO	0209	BE	Drums

1.4 ABS	7/97-8/00	AT	0223	LU	Drums
1.4 Break	5/98-8/00	AT	0223	BE	Drums
1.4 Break	5/98-8/00	LU	0306	BE	Drums
1.4 Break	5/98-8/00	BO	0307	BE	Drums
1.6	7/97-8/00	AT	0223	LU	Drums
1.6	7/97-8/00	AT	0223	BE	Drums
1.6 ABS	7/97-8/00	AT	0223	LU	Drums
1.6 Break	5/98-8/00	AT	0223	BE	Drums
1.6 Break	5/98-8/00	LU	0306	BE	Drums
1.6 Break	5/98-8/00	BO	0307	BE	Drums
1.8 Automatic	7/97-8/00	BO	0209	LU	Drums
1.8 Automatic	7/97-8/00	BO	0209	BE	Drums
1.8 Automatic ABS	7/97-8/00	AT	0223	LU	Drums
1.8 Break	5/98-8/00	AT	0223	BE	Drums
1.8 Break	5/98-8/00	LU	0306	BE	Drums
1.8 Break	5/98-8/00	BO	0307	BE	Drums
1.8 SX-VTS-X	7/97-8/00	LU	0306	BE	0227
1.8 SX-VTS-X	7/97-8/00	BO	0307	BE	0227
1.9 D	7/97-8/00	BO	0209	LU	Drums
1.9 D	7/97-8/00	BO	0209	BE	Drums
1.9 D ABS	7/97-8/00	AT	0223	LU	Drums
1.9 D Break	5/98-8/00	AT	0223	BE	Drums
1.9 D Break	5/98-8/00	LU	0306	BE	Drums
1.9 D Break	5/98-8/00	BO	0307	BE	Drums
1.9 TD	7/97-8/00	BO	0209	LU	Drums
1.9 TD	7/97-8/00	BO	0209	BE	Drums
1.9 TD ABS	7/97-8/00	AT	0223	LU	Drums
1.9 TD Break	5/98-8/00	AT	0223	BE	Drums
1.9 TD Break	5/98-8/00	LU	0306	BE	Drums
1.9 TD Break	5/98-8/00	BO	0307	BE	Drums
2.0 VTS	1/98-8/00	LU	0306	BE	0227
2.0 VTS	1/98-8/00	BO	0307	BE	0227
2.0 HDi	6/99-8/00	LU	0306	BE	0227
2.0 HDi	6/99-8/00	BO	0307	BE	0227
Xsara 00-					
1.4	9/00-	BO	0309	LU	Drums
1.6	9/00-	BO	0309	BE	0227
1.9	9/00-	BO	0309	BE	0227
2.0 (90HP)	9/00-	BO	0309	BE	0227
2.0 (110HP)	1/02-	BO	1472	BE	0227
Xsara Picasso					
1.6	9/99-10/01	LU	0766	LU	Drums
1.6	11/01-	BO	0309	LU	Drums
1.6	1/03-	BO	1472	BE	0227
1.8	9/99-10/01	LU	0766	LU	Drums
1.8	11/01-	BO	0309	LU	Drums
1.8	1/03-	BO	1472	BE	0227
2.0	9/99-10/01	LU	0766	LU	Drums
2.0	11/01-	BO	0309	LU	Drums
2.0	1/03-	BO	1472	BE	0227
ZX					

1.1	7/91-10/97	BE	0207	LU	Drums
1.1	7/91-10/97	BE	0207	BE	Drums
1.4	7/91-10/97	BE	0207	LU	Drums
1.4	7/91-10/97	BE	0207	BE	Drums
1.6	7/91-10/97	LU	0183P	LU	Drums
1.6	7/91-10/97	LU	0183P	BE	Drums
1.6 Break	7/91-10/97	LU	0183P	BE	Drums
1.6 (ABS)	7/94-10/97	LU	0183P	LU	Drums
1.8	7/91-10/97	LU	0183P	LU	Drums
1.8	7/91-10/97	LU	0183P	BE	Drums
1.8 (ABS)	7/94-10/97	LU	0183P	LU	Drums
1.9	7/91-6/94	LU	0183P	LU	Drums
1.9	7/91-6/94	LU	0183P	BE	Drums
1.9 (ABS)	7/91-6/94	LU	0183P	LU	Drums
1.9 Diesel	7/91-10/97	LU	0250	LU	Drums
1.9 Diesel	7/91-10/97	BE	0207	BE	Drums
1.9 Diesel (ABS)	7/91-6/94	LU	0250	BE	0227
1.9 Diesel (ABS)	7/91-6/94	BE	0207	BE	0227
1.9 Diesel (ABS)	7/94-10/97	LU	0250	LU	Drums
1.9 Diesel (ABS)	7/94-10/97	BE	0207	LU	Drums
1.9 Diesel Break	7/94-10/97	LU	0183P	BE	Drums
1.9 TD	7/94-10/97	LU	0183P	BE	0227
1.9 TD Break	7/94-10/97	LU	0183P	BE	Drums
2.0 Volcane	6/92-10/97	LU	0183P	BE	0227
2.0 16V Volcane	6/92-10/97	LU	T.B.A.	BE	Drums