

<b>FORD</b>			ant/front		post/rear
<b>Capri I</b>					
1.3	11/68-1/74	LU	0029	LU	Drums
1.5	9/69-12/73	LU	0029	LU	Drums
1.6	72-12/73	LU	0066	LU	Drums
1.7	9/69-8/70	LU	0029	LU	Drums
1.7	9/70-9/72	LU	0066	LU	Drums
2.0	9/69-8/70	LU	0053	LU	Drums
2.0	9/70-11/74	LU	0066	LU	Drums
2.3	9/69-8/70	LU	0053	LU	Drums
2.3	9/70-11/74	LU	0066	LU	Drums
2.6	9/69-2/74	LU	0066	LU	Drums
3.0	9/70-11/74	LU	0066	LU	Drums
<b>Capri II &amp; III</b>					
1.3	12/74-2/87	LU	0066	LU	Drums
1.6	12/74-2/87	LU	0066	LU	Drums
2.0	12/74-2/87	LU	0066	LU	Drums
2.3	12/74-2/87	LU	0066	LU	Drums
2.8 injection	4/81-2/87	LU	0066	LU	Drums
3.0	12/74-2/87	LU	0066	LU	Drums
<b>Cortina I &amp; II</b>					
1.2	1/64-1/65	LU	0029	LU	Drums
1.3	9/66-8/70	LU	0029	LU	Drums
1.5 GT	1/64-1/65	LU	0053	LU	Drums
1.5 Lotus	1/64-1/65	LU	0053	LU	Drums
1.6 GT	9/66-8/70	LU	0029	LU	Drums
1600E	9/66-8/70	LU	0029	LU	Drums
<b>Cortina III IV &amp; V</b>					
1.3	9/70-8/82	LU	0066	LU	Drums
1.6	9/70-8/82	LU	0066	LU	Drums
2.0	9/70-8/82	LU	0066	LU	Drums
2.3 V6	9/70-8/82	LU	0066	LU	Drums
<b>Cougar</b>					
2.0 16v	8/98-12/01	AT	0723	BE	0868
2.5 V6 24v	8/98-10/03	AT	0723	BE	0868
2.5 V6 ST 200	2/00-10/03	AT	0723	BE	0868
<b>Escort I &amp; II</b>					
1.1	8/69-11/74	LU	0028	LU	Drums
1.1	12/74-8/80	LU	0066	LU	Drums
1.3	8/69-11/74	LU	0028	LU	Drums
1.3	12/74-8/80	LU	0066	LU	Drums
1300 Sport	12/74-8/80	LU	0066	LU	Drums
1.6	12/74-8/80	LU	0066	LU	Drums
1600 Sport/Mexico	12/74-8/80	LU	0066	LU	Drums
RS1600 Twin Cam	4/68-9/71	LU	0053	LU	Drums
RS2000	3/72-8/80	LU	0066	LU	Drums
<b>Escort III &amp; IV</b>					
1.1	9/80-8/90	AT	0165	LU	Drums
1.3	9/80-8/90	AT	0165	LU	Drums
1.4	3/86-8/90	AT	0165	LU	Drums
1.6	9/80-8/90	AT	0165	LU	Drums

1.6 Diesel	3/86-8/90	AT	0165	LU	Drums
1.6 RS Turbo S1	85-2/86	AT	0165	LU	Drums
1.6 RS Turbo S2	3/86-8/90	AT	0247	LU	Drums
1.6 XR3	9/80-3/82	AT	0165	LU	Drums
1.6 XR3i	3/82-8/90	AT	0165	LU	Drums
1.8 Diesel	3/86-8/90	AT	0165	LU	Drums
<b>Escort V &amp; VI</b>					
1.3	9/90-9/97	BE	0449	AT	0896
1.4	9/90-4/00	BE	0449	AT	0896
1.6	9/90-4/00	BE	0449	AT	0896
1.6 4x4	9/90-4/00	AT	0247	AT	0896
1.8 Diesel	9/90-8/00	BE	0449	AT	0896
1.8 Turbo Diesel	9/90-8/00	BE	0449	AT	0896
1.8 16V	7/97-8/00	BE	0449	AT	0896
1.8 16V	9/90-8/00	AT	0247	AT	0896
1.8 16V XR3i	9/90-8/00	AT	0247	AT	0896
2.0 RS2000	9/90-12/94	AT	0247	AT	0896
2.0 RS2000 4x4	9/90-12/94	AT	0247	AT	0896
2.0 Cosworth 4WD	1/95-10/96	AT	0315	LU	0248
<b>Fiesta I &amp; II</b>					
950	5/75-8/83	BE	0091	BE	Drums
950	9/83-2/89	AT	0288	BE	Drums
1.1	5/75-8/83	BE	0091	BE	Drums
1.1	9/83-2/89	AT	0288	BE	Drums
1.3	5/75-8/83	BE	0091	BE	Drums
1.3	9/83-2/89	AT	0288	BE	Drums
1.4	9/83-2/89	AT	0288	BE	Drums
1.6 Diesel	9/83-2/89	AT	0288	BE	Drums
1.6 XR2	9/81-8/83	AT	0199	BE	Drums
1.6 XR2	9/83-2/89	AT	0165	BE	Drums
<b>Fiesta III &amp; IV</b>					
1.1	3/89-8/95	AT	0288	BE	Drums
1.1 Auto	3/89-8/95	AT	0288	BE	Drums
1.1 Auto (vented discs)	3/89-8/95	AT	0165	BE	Drums
1.25 (solid discs)	9/95-8/99	AT	0746	LU	Drums
1.25 (vented discs)	9/95-8/99	AT	0745	LU	Drums
1.3	3/89-8/95	AT	0288	BE	Drums
1.3 Auto	3/89-8/95	AT	0288	BE	Drums
1.3 Auto (vented discs)	3/89-8/95	AT	0165	BE	Drums
1.4	3/89-8/95	AT	0288	BE	Drums
1.4 (vented discs)	3/89-8/95	AT	0165	BE	Drums
1.4 Auto	3/89-8/95	AT	0288	BE	Drums
1.4 Auto (vented discs)	3/89-8/95	AT	0165	BE	Drums
1.4 (solid discs)	9/95-8/99	AT	0746	LU	Drums
1.4 (vented discs)	9/95-8/99	AT	0745	LU	Drums
1.6	3/89-8/95	AT	0288	BE	Drums
1.6 (vented discs)	3/89-8/95	AT	0165	BE	Drums
1.6 (vented discs)	9/95-8/99	AT	0745	LU	Drums
1.6 RS Turbo	3/89-8/95	AT	0165	BE	Drums
1.6 XR2i	3/89-8/95	AT	0165	BE	Drums
1.6 16v XR2i	3/89-8/95	AT	0165	BE	Drums

1.8 RS1800	3/89-8/95	AT	0165	BE	Drums
1.8 Diesel	3/89-9/91	AT	0288	BE	Drums
1.8 Diesel (ABS)	3/89-9/91	AT	0165	BE	Drums
1.8 Diesel	10/91-8/95	AT	0165	BE	Drums
1.8 Diesel (ABS)	10/91-8/95	AT	0165	BE	Drums
1.8 Diesel (solid disc)	9/95-8/99	AT	0746	LU	Drums
1.8 Diesel (vented disc)	9/95-8/99	AT	0745	LU	Drums
<b>Fiesta V</b>					
1.2 (ABS)	2/00-	AT	0450	LU	Drums
1.2	2/00-	AT	0747	LU	Drums
1.3 (ABS)	2/00-	AT	0450	LU	Drums
1.3	2/00-	AT	0747	LU	Drums
1.4 (ABS)	2/00-	AT	0450	LU	Drums
1.6 (ABS)	2/00-	AT	0450	LU	Drums
1.8 (ABS)	2/00-	AT	0450	LU	Drums
1.8	2/00-	AT	0747	LU	Drums
2.0 ST150	2/00-	AT	0887	LU	0444
<b>Focus I</b>					
1.4 16V	10/98-11/04	AT	0446	LU	Drums
1.6 16V	10/98-11/04	AT	0446	LU	Drums
1.8 16V	10/98-11/04	AT	0446	LU	0444
1.8 Turbo D	10/98-11/04	AT	0446	LU	Drums
2.0 16V	10/98-11/04	AT	0446	LU	0444
2.0 ST170	2/01-11/04	AT	0887	LU	0444
2.0 RS	10/02-11/03	BR	0331	LU	0444
<b>Focus II</b>					
1.4	11/04-	AT	0888	AT	0883
1.6 Ti	11/04-	AT	0888	AT	0883
1.6 TDCi	11/04-	AT	0888	AT	0883
2.0	11/04-	AT	0888	AT	0883
2.0 TDCi	11/04-	AT	0888	AT	0883
2.5 ST	1/05-	AT	0898	AT	0883
2.5 RS	09-	AT	T.B.A	AT	T.B.A
<b>Focus C-Max</b>					
1.6	10/03-	AT	0888	AT	1527
1.6 TDCi	10/03-	AT	0888	AT	1527
1.8	10/03-	AT	0888	AT	1527
2.0 TDCi	10/03-	AT	0888	AT	1527
<b>Fusion</b>					
1.4	8/02-	AT	0450	LU	Drums
1.6	8/02-	AT	0450	LU	Drums
<b>Galaxy I</b>					
1.9 TDi (15")	5/95-4/00	AT	0459	LU	0305
1.9 TDi (16")	5/95-4/00	AT	0457	LU	0305
1.9 TDi (16")	5/00-	AT	0459	LU	T.B.A
1.9 TDi (17")	5/00-	AT	0469	LU	0470
2.0 (15")	5/95-4/00	AT	0459	LU	0305
2.0 (16")	5/95-4/00	AT	0457	LU	0305
2.3 (15")	9/96-4/00	AT	0459	LU	0305
2.3 (16")	5/95-4/00	AT	0457	LU	0305
2.3 (16")	5/00-	AT	0459	LU	T.B.A

2.3 (17")	5/00-	AT	0469	LU	0470
2.8 (15")	5/95-4/00	AT	0459	LU	0305
2.8 (16")	5/95-4/00	AT	0457	LU	0305
2.8 (17")	5/00-	AT	0469	LU	0470
<b>Galaxy II</b>					
1.8	5/06-	AT	T.B.A	LU	T.B.A
2.0	5/06-	AT	T.B.A	LU	T.B.A
2.0 TDCI	5/06-	AT	T.B.A	LU	T.B.A
<b>Granada I &amp; II</b>					
1.7	12/74-7/81	LU	0066	LU	Drums
2.0	12/74-7/85	LU	0066	LU	Drums
2.1 Diesel	9/78-8/82	LU	0066	LU	Drums
2.3	2/72-9/74	AT	0067A	LU	Drums
2.3	10/74-7/85	LU	0066	LU	Drums
2.5 Diesel	8/81-7/85	LU	0066	LU	Drums
2.5 Diesel Estate	8/81-7/85	LU	0193	LU	Drums
2.6	2/72-9/74	AT	0067A	LU	Drums
2.6	10/74-9/77	LU	0066	LU	Drums
2.8	2/72-7/81	LU	0139	LU	Drums
2.8	8/81-7/85	LU	0193	LU	Drums
3.0	2/72-9/74	AT	0067A	LU	Drums
3.0	10/74-9/77	LU	0066	LU	Drums
<b>Granada III</b>					
2.0	10/84-9/91	AT	0247	LU	0248
2.0	9/90-10/92	AT	0247	LU	0248A
2.0	11/92-9/93	AT	0723	LU	0248
2.5 TD	9/85-9/91	AT	0247	LU	0248
2.5 TD	9/85-10/92	AT	0247	LU	0248A
2.5 TD	11/92-9/94	AT	0723	LU	0248A
<b>Ka</b>					
1.3	9/96-2/00	AT	0288	LU	Drums
1.3	9/96-2/00	AT	0746	LU	Drums
1.3	3/00-	AT	0747	LU	Drums
<b>Maverick</b>					
2.0	5/00-	AT	T.B.A	BE	Drums
2.4	2/93-4/00	LU	0761	LU	Drums
2.7	2/93-4/00	LU	0761	LU	Drums
3.0	5/00-	AT	T.B.A	BE	Drums
<b>Mondeo I</b>					
1.6 16v	3/93-9/96	AT	0723	BE	0868
1.8 16v	3/93-9/96	AT	0723	BE	0868
1.8 TD	3/93-9/96	AT	0723	BE	0868
2.0 16v	3/93-9/96	AT	0723	BE	0868
2.5 24v	7/94-9/96	AT	0723	BE	0868
<b>Mondeo II</b>					
1.6 16v	9/96-9/00	AT	0723	BE	0868
1.8 16v	9/96-11/00	AT	0723	BE	0868
1.8 TD	9/96-11/00	AT	0723	BE	0868
2.0 16v (ABS)	9/96-9/00	AT	0723	BE	0868
2.0 16v (15")	9/96-11/00	AT	0315	BE	0868
2.5 V6	9/96-11/00	AT	0315	BE	0868

<b>Mondeo III</b>					
1.6 16v	10/00-12/04	BO	0884	BO	0885
1.6 16v	1/05-	BO	0884	BO	T.B.A
1.8 SCi	10/00-12/04	BO	0884	BO	0885
1.8 SCi	1/05-	BO	0884	BO	T.B.A
1.8 TDCi	10/01-	BO	0884	BO	0885
2.0 16v	10/00-12/04	BO	0884	BO	0885
2.0 16v	1/05-	BO	0884	BO	T.B.A
2.0 TDi	10/00-12/04	BO	0884	BO	0885
2.0 TDi	1/05-	BO	0884	BO	T.B.A
2.2 TDCi	10/01-12/04	BO	0884	BO	0885
2.2 TDCi	1/05-	BO	0884	BO	T.B.A
2.5 V6 24v	10/00-12/04	BO	0884	BO	0885
2.5 V6 24v	1/05-	BO	0884	BO	T.B.A
3.0 ST 220	10/01-12/04	BO	0884	BO	0885
3.0 V6	1/05-	BO	0884	BO	T.B.A
<b>Mondeo IV</b>					
1.6 Ti	3/07-	AT	T.B.A	LU	T.B.A
1.8 TDCI	3/07-	AT	T.B.A	LU	T.B.A
2.0	3/07-	AT	T.B.A	LU	T.B.A
2.0 TDCI	3/07-	AT	T.B.A	LU	T.B.A
2.3	3/07-	AT	T.B.A	LU	T.B.A
2.5 20V	3/07-	AT	T.B.A	LU	T.B.A
<b>Orion I &amp; II</b>					
1.3	9/83-8/90	AT	0165	LU	Drums
1.4	3/86-8/90	AT	0165	LU	Drums
1.6	9/83-8/90	AT	0165	LU	Drums
1.6i	3/86-8/90	AT	0165	LU	Drums
1.8 Diesel	10/84-8/90	AT	0165	LU	Drums
<b>Orion III</b>					
1.4	9/90-8/93	BE	0449	LU	Drums
1.6	9/90-8/93	BE	0449	LU	Drums
1.8 Diesel	9/90-8/93	BE	0449	LU	Drums
1.8 Turbo Diesel	9/90-8/93	BE	0449	LU	Drums
<b>Probe</b>					
2.0	6/92-10/94	AK	T.B.A	SU	T.B.A
2.0	1/93-98	SU	0753	AK	T.B.A
2.5 24V	6/92-10/94	AK	T.B.A	SU	T.B.A
2.5 24V	1/93-98	SU	0753	AK	T.B.A
<b>Puma</b>					
1.4	2/98-2/00	AT	0745	LU	Drums
1.4	3/00-	AT	0450	LU	Drums
1.7 16V	6/97-2/00	AT	0745	LU	Drums
1.7 16V	3/00-	AT	0450	LU	Drums
<b>S-Max</b>					
1.8 TDCi	5/06-	AT	T.B.A	LU	T.B.A
2.0	5/06-	AT	T.B.A	LU	T.B.A
2.0 TDCi	5/06-	AT	T.B.A	LU	T.B.A
2.5 ST	5/06-	AT	T.B.A	LU	T.B.A
<b>Scorpio</b>					
1.8	10/94-8/92	AT	0247	LU	0248

1.8	10/94-8/92	AT	0723	LU	0248
1.8	9/92-3/95	AT	0723	LU	0248A
2.0	10/94-8/92	AT	0247	LU	0248
2.0	10/94-8/92	AT	0723	LU	0248
2.0	9/92-3/95	AT	0723	LU	0248A
2.0 16V	10/94-8/98	AT	0723	LU	0248
2.0 16V	10/94-8/98	AT	0723	LU	0248A
2.3 V6	10/94-8/98	AT	0723	LU	0248
2.3 V6	10/94-8/98	AT	0723	LU	0248A
2.4 V6	10/94-8/92	AT	0247	LU	0248
2.4 V6	10/94-8/92	AT	0723	LU	0248
2.4 V6	9/92-3/95	AT	0723	LU	0248A
2.5 Diesel	10/94-8/92	AT	0247	LU	0248
2.5 Diesel	10/94-8/92	AT	0723	LU	0248
2.5 Diesel	9/92-3/95	AT	0723	LU	0248A
2.5 TD	10/94-8/92	AT	0247	LU	0248
2.5 TD	10/94-8/92	AT	0723	LU	0248
2.5 TD	9/92-3/95	AT	0723	LU	0248A
2.8 V6	10/94-8/92	AT	0247	LU	0248
2.8 V6	10/94-8/92	AT	0723	LU	0248
2.8 V6	9/92-3/95	AT	0723	LU	0248A
2.9 V6	10/94-8/92	AT	0247	LU	0248
2.9 V6	10/94-8/92	AT	0723	LU	0248
2.9 V6	9/92-3/95	AT	0723	LU	0248A
2.9 V6 24V	4/91-8/92	AT	0247	LU	0248
2.9 24V	8/92-8/98	AT	0315	LU	0248A
<b>Sierra I</b>					
1.3	8/82-2/87	LU	0196	LU	Drums
1.6	8/82-2/87	LU	0196	LU	Drums
1.6 (ABS)	8/82-2/87	AT	0247	LU	0248
1.6 Estate	8/82-10/84	LU	0196	LU	Drums
1.6 Estate	11/84-2/87	AT	0165	LU	Drums
1.6 Estate (ABS)	8/82-2/87	AT	0247	LU	0248
1.8	8/82-2/87	AT	0165	LU	Drums
1.8 (ABS)	8/82-2/87	AT	0247	LU	0248
1.8 Estate	8/82-2/87	AT	0165	LU	Drums
1.8 Estate (ABS)	8/82-2/87	AT	0247	LU	0248
2.0	8/82-2/87	AT	0165	LU	Drums
2.0 (ABS)	8/82-2/87	AT	0247	LU	0248
2.0 Estate	8/82-2/87	AT	0165	LU	Drums
2.0 Estate (ABS)	8/82-2/87	AT	0247	LU	0248
2.0 RS Cosworth	6/86-2/87	LU	O271	LU	0248
2.0 RS500 Cosworth	6/86-2/87	LU	O271	LU	0248
2.3	8/82-2/87	AT	0165	LU	Drums
2.3 (ABS)	8/82-2/87	AT	0247	LU	0248
2.3 Estate	8/82-2/87	AT	0165	LU	Drums
2.3 Estate (ABS)	8/82-2/87	AT	0247	LU	0248
2.3 Diesel	8/82-2/87	AT	0165	LU	Drums
2.3 Diesel (ABS)	8/82-2/87	AT	0247	LU	0248
2.3 Diesel Estate	8/82-2/87	AT	0165	LU	Drums
2.3 Diesel Estate (ABS)	8/82-2/87	AT	0247	LU	0248

2.8 XR4i	8/82-2/87	AT	0247	LU	Drums
2.8 XR4x4	8/82-2/87	AT	0247	LU	0248
2.8 4x4 Estate	8/82-2/93	AT	0247	LU	0248
<b>Sierra II</b>					
1.3	3/87-2/93	LU	0196	LU	Drums
1.6	3/87-2/93	LU	0196	LU	Drums
1.6	3/87-2/93	AT	0165	LU	Drums
1.6 (ABS)	3/87-2/93	AT	0247	LU	0248
1.6 Estate	3/87-2/93	AT	0165	LU	Drums
1.6 Estate (ABS)	3/87-2/93	AT	0247	LU	0248
1.8	3/87-2/93	AT	0165	LU	Drums
1.8 (ABS)	3/87-2/93	AT	0247	LU	0248
1.8 Estate	3/87-2/93	AT	0165	LU	Drums
1.8 Estate (ABS)	3/87-2/93	AT	0247	LU	0248
2.0	3/87-2/93	AT	0165	LU	Drums
2.0 (ABS)	3/87-2/93	AT	0247	LU	0248
2.0 Estate	3/87-2/93	AT	0165	LU	Drums
2.0 Estate (ABS)	3/87-2/93	AT	0247	LU	0248
2.0 16v	2/89-2/93	AT	0247	LU	0248
2.0 Cosworth 2x4	5/88-8/90	AT	0271	LU	0248
2.0 Cosworth 4x4	8/90-7/93	AT	0315	LU	0248
2.3 Diesel	3/87-2/93	AT	0165	LU	Drums
2.3 Diesel (ABS)	3/87-2/93	AT	0247	LU	0248
2.3 Diesel Estate	3/87-2/93	AT	0165	LU	Drums
2.3 Diesel Estate (ABS)	3/87-2/93	AT	0247	LU	0248
2.8 XR4x4	5/88-2/93	AT	0247	LU	0248
2.8 4x4 Estate	5/88-2/93	AT	0247	LU	0248
2.9 XR4x4	5/88-2/93	AT	0247	LU	0248
2.9 4x4 Estate	5/88-2/93	AT	0247	LU	0248
<b>Sport Ka</b>					
1.6	5/03-	AT	0450	LU	Drums
<b>Street Ka</b>					
1.6	5/03-	AT	0450	LU	Drums
<b>Taunus -71</b>					
1.7 17M (P5/P7)	68-71	AT	0097		Drums
2.0 20M (P5/P7)	68-71	AT	0037		Drums
2.3 20M (P7)	68-71	AT	0037		Drums
<b>Taunus 70-</b>					
1.3	9/70-8/82	LU	0066	LU	Drums
1.6	9/70-8/82	LU	0066	LU	Drums
2.0	9/70-8/82	LU	0066	LU	Drums
2.3 V6	9/70-8/82	LU	0066	LU	Drums