

<b>HONDA</b>			ant/front		post/rear
<b>Accord II</b>					
1.6 (AC/AD)	83-5/85	AK	0750	AT	Drums
1.6 (AC/AD)	83-5/85	AK	1526	AT	Drums
1.6 (ABS) (AC/AD)	83-5/85	AK	0750	AK	T.B.A.
1.6 (AAC)	84-8/85	AK	2278	AT	Drums
1.8	84-7/85	AK	2278	AT	Drums
1.8 (SY/SZ)	81-6/83	AK	1526	AT	Drums
1.8 (AC/AD)	83-6/85	AK	0750	AT	Drums
1.8 (AC/AD)	83-6/85	AK	1526	AT	Drums
1.8 (AAD)	83-6/85	AK	2278	AT	Drums
1.8 (AAD) (ABS)	83-6/85	AK	2278	AK	T.B.A.
1.8 (AD)	83-6/85	AK	2278	AT	Drums
<b>Accord III</b>					
1.6 (CA/CA5)	9/85-9/89	AK	T.B.A.	AT	Drums
1.8 (CA1)	85-7/87	AK	1571	AK	Drums
2.0 (CA5)	1/88-12/89	AK	1470	AT	Drums
2.0 (CA/6)	1/88-12/89	AK	1470	AK	T.B.A.
2.0 (CA/6)	1/88-12/89	AK	1815	AK	T.B.A.
<b>Accord IV</b>					
1.8 (CE7)	1/96-9/98	AK	2279	AK	2291
1.8 (CE7)	1/96-9/98	AK	1653	AK	2291
2.0 TDi (CF1)	1/93-9/98	AK	1653	AK	2291
2.0 TDi (CF1) (ABS)	1/93-9/98	AK	2279	AK	2291
2.0 (CV8/9-CC9)	1/93-12/93	AK	2279	AK	2291
2.0 Coupè (CC1)	4/92-5/94	AK	T.B.A.	AK	2291
2.0 Coupè (CB7)	89-11/93	SU	T.B.A.	AK	2291
2.0 Coupè (CB9)	89-11/93	AK	2279	AK	2291
2.0 Coupè (115HP)	9/93-2/98	AK	T.B.A.	AK	2291
2.0 (CC7-CE8)	1/93-9/98	AK	1653	AK	2291
2.0 (CC7-CE8) (ABS)	1/93-9/98	AK	2279	AK	2291
2.0 (CE2)	1/93-12/93	AK	2279	AK	2291
2.0 (CC9)	1/94-10/97	AK	2279	AK	2291
2.2 Coupè (CD7)	9/89-7/93	AK	T.B.A.	AK	2291
2.2 Coupè (CD7)	8/93-12/97	AK	2279	AK	2291
2.2 4WD (CB7)	1/90-12/92	AK	T.B.A.	AK	2291
2.2 (CB8/9-CC1)	1/90-10/97	AK	2279	AK	2291
2.2 (CB8/9-CC1)	1/90-10/97	AK	T.B.A.	AK	2291
2.2 Vtec 16V (CE9)	1/96-9/98	AK	1653	AK	2291
2.2 Vtec 16V(ABS)(CE9)	1/96-9/98	AK	2279	AK	2291
2.3 (CC7)	1/93-12/95	AK	1653	AK	2291
2.3 (ABS) (CC7)	1/93-12/95	AK	2279	AK	2291
<b>Accord V</b>					
1.6 (CG7-CH5)	10/98-1/03	SU	2204	LU	Drums
1.6 (CG7-CH5) (ABS)	10/98-1/03	SU	2204	LU	T.B.A.
1.8 (CH6)	10/98-1/03	SU	0398	LU	T.B.A.
2.0 TDiC (ABS)	10/98-1/03	SU	0398	LU	T.B.A.
2.0 Vtec (CG9-CH2/7/8)	10/98-1/03	SU	0398	LU	T.B.A.
<b>Accord VI</b>					
2.0 (CL8)	2/03-	AK	2206	LU	T.B.A.
2.0 VTEC	2/03-	AK	2294	LU	T.B.A.

2.0 VTEC (Tourer)	2/03-	AK	2294	AK	2291
2.2 CDTi	2/03-	AK	2294	LU	T.B.A.
2.2 CDTi (Tourer)	2/03-	AK	2294	AK	2291
2.2 CDTi	1/04-	AK	2206	LU	T.B.A.
2.4 (CL9)	2/03-	AK	2206	LU	T.B.A.
2.4 VTEC	2/03-	AK	2294	LU	T.B.A.
2.4 VTEC (Tourer)	2/03-	AK	2294	AK	2291
<b>Civic II</b>					
1.3 (AWC)	1/80-12/83	AK	0113	SU	Drums
1.3 (ASL-ASS)	1/80-12/81	SU	1220	SU	Drums
<b>Civic III</b>					
1.3	1/84-12/87	SU	T.B.A.	AK	Drums
1.5	1/84-12/87	SU	T.B.A.	AK	Drums
1.6	2/87-88	AK	1526	AK	Drums
<b>Civic IV</b>					
1.2 (EC7-ED1)	1/88-12/91	AK	1526	AK	Drums
1.4 (3 doors) (ED2)	1/88-12/91	AK	T.B.A.	AK	Drums
1.4 (4 doors) (EC9)	1/88-12/91	AK	1526	AK	Drums
1.5 (ED6)	1/88-12/88	AK	1571	AK	Drums
1.5 (ED6)	1/89-12/91	AK	T.B.A.	AK	Drums
1.5 (ED3/6)	1/88-12/91	AK	T.B.A.	AK	Drums
1.6 4x4 (EE5)	1/88-12/88	AK	1571	AK	Drums
1.6 4x4 (EE5)	1/89-12/91	AK	T.B.A.	AK	Drums
1.6 (ED4/7)	1/88-12/91	AK	T.B.A.	AK	T.B.A.
1.6 VTEC (EE9)	1/90-12/91	AK	T.B.A.	AK	T.B.A.
<b>Civic V</b>					
1.3 (EG3)	1/92-12/95	AK	1526	AK	Drums
1.5 (EJ2)	2/94-12/95	SU	1816P	AT	Drums
1.5 (EG8)	8/94-12/95	SU	1816P	AT	Drums
1.5 (EG8-EJ2)	1/92-12/95	SU	1816P	AK	Drums
1.5 (EG4)	1/92-12/95	SU	1816P	AK	Drums
1.5 (ABS) (EG8)	1/93-12/95	SU	1816P	AK	T.B.A.
1.6 (EG9)	8/93-12/95	SU	1816G	AK	T.B.A.
1.6 ESi VTEC (EH9)	8/91-12/92	SU	1816P	AK	Drums
1.6 ESi VTEC (EH9) (ABS)	8/91-12/94	SU	1816G	AK	T.B.A.
1.6 ESi VTEC (EG5)	1/92-12/95	SU	1816P	AK	T.B.A.
1.6 ESi VTEC (EJ1)	8/93-12/95	SU	1816G	AT	Drums
1.6 (EH9) (ABS)	8/93-12/95	SU	1816G	AK	T.B.A.
1.6 RTSi VTEC (EH1)	8/91-12/92	SU	1816P	AK	Drums
1.6 RTSi VTEC (EH1) (ABS)	1/92-12/95	SU	1816G	AK	T.B.A.
1.6 VTi VTEC (EG5)	1/92-12/92	SU	1816P	AK	T.B.A.
1.6 VTi VTEC (EG6/9)	1/92-12/95	SU	1816G	AK	T.B.A.
<b>Civic VI</b>					
1.4 (MA8)	2/95-12/96	LU	1675	LU	Drums
1.4 (MA8) (ABS)	2/95-12/96	LU	1675	AK	1572
1.4 (EJ9)	1/96-12/97	SU	1816P	AK	Drums
1.5 (EK3)	1/96-3/01	SU	1816G	AT	Drums
1.5 VTEC-E (MA8)	2/95-12/96	LU	1675	LU	Drums
1.5 VTEC-E (ABS) (MA8)	2/95-12/96	LU	1675	AK	1572
1.6 (EJ6)	1/96-3/01	SU	1816P	AT	Drums
1.6 (EJ6)	1/96-3/01	SU	1816G	AT	Drums

1.6 (MB1)	2/95-12/96	LU	1675	AK	1572
1.6 SR VTEC (EJ8)	1/96-3/01	SU	1816G	AT	Drums
1.6 SRi VTEC (MB1) (ABS)	2/95-12/96	LU	1675	AK	1572
1.6 VTi (3 Drs) (EK4)	1/96-3/01	SU	1816G	AK	T.B.A.
1.6 VTi (4 Drs) (EK4)	1/96-3/01	SU	1816P	AK	T.B.A.
<b>Civic VII</b>					
1.7 CDTi	1/02-	AK	2290	AK	2291
2.0 TDiC	01/97-10/00	LU	1675	AK	1572
2.0 Type R (EP3)	7/01-12/06	AK	2290	AK	2291
<b>Civic VIII</b>					
1.3 Hybrid	1/06-	LU	2208	LU	T.B.A.
1.3	1/06-	LU	2208	LU	T.B.A.
1.8	1/06-	LU	2208	LU	T.B.A.
2.0 Type R (FN2)	1/07-	AK	2290		
2.2 CDTi	1/06-	LU	2208	LU	T.B.A.
<b>Civic Aerodeck</b>					
1.4 (MB8)	4/98-2/01	LU	1675	LU	Drums
1.5 (MB8)	4/98-2/01	LU	1675	LU	Drums
1.6 (MC1)	4/98-2/01	LU	1675	AK	1572
1.8 (MC2)	4/98-2/01	AK	2279	AK	2291
<b>Civic CRX</b>					
1.4 (EE6)	1/90-12/91	AK	1526	AK	Drums
1.5 (AAF)	85-9/88	AK	T.B.A.	AK	Drums
1.5 (AAS)	85-9/88	AK	T.B.A.	AK	Drums
1.6 (ED9)	86-9/88	AK	1571	AK	T.B.A.
1.6 (ED9-EE6/8)	88-2/92	AK	1815	AK	T.B.A.
1.6 DelSol ESi (EH6)	5/92-1/94	SU	1816G	AK	T.B.A.
1.6 DelSol VTi VTEC (EE8)	92-1/94	SU	1816G	AK	T.B.A.
1.6 DelSol (EJ1/6/8)	2/94-12/98	SU	1816G	AK	Drums
1.6 DelSol (EJ1/6/8)	2/94-12/98	SU	1816P	AK	Drums
<b>Civic Shuttle</b>					
1.4 (EE1)	1/88-12/89	AK	2278	AK	Drums
1.4 (EE1)	1/90-12/91	AK	T.B.A.	AK	Drums
1.5 4WD (AR)	9/85-1/88	SU	T.B.A.	AK	Drums
1.5 (AN)	9/83-1/88	SU	T.B.A.	AK	Drums
1.5 (AN)	2/88-12/89	AK	2278	AK	Drums
1.5 (EE1/2)	6/88-1/92	AK	2278	AK	Drums
1.6 4WD (Cat.)	2/88-10/91	AK	2278	AK	Drums
1.6 4WD (ABS)	11/91-12/96	AK	T.B.A.	AK	Drums
<b>Concerto</b>					
1.4	10/89-7/91	LU	1660	LU	Drums
1.5	10/89-8/90	LU	1660	AK	Drums
1.5	9/90-5/95	LU	1675	AK	1572
1.6	10/89-8/90	LU	1660	AK	Drums
1.6	9/90-5/95	LU	1660	LU	Drums
1.6	9/90-5/95	LU	1675	AK	1572
1.6 16V	9/90-5/95	AK	T.B.A.	AK	Drums
1.6 16V	9/90-5/95	LU	1660	LU	Drums
1.6 16V SX	9/90-5/95	LU	1675	AK	1572
1.8 Diesel	8/94-10/96	LU	1675	LU	Drums
1.8 Diesel (ABS)	8/94-10/96	LU	1675	AK	1572

<b>CR-V</b>					
2	7/02-	AK	2206	AK	2291
<b>HR-V</b>					
1.6	1/99-	AK	T.B.A.	AK	Drums
<b>Insight</b>					
1	4/00-	AK	T.B.A.		
<b>Integra</b>					
1.5 (3 doors) (DA4)	86-5/90	AK	T.B.A.	AK	Drums
1.5 (4 doors) (DA4)	86-5/90	AK	T.B.A.	AK	T.B.A.
1.6 (3 doors) (DA3)	86-5/90	AK	T.B.A.	AK	Drums
1.6 (4 doors) (DA3)	86-5/90	AK	T.B.A.	AK	T.B.A.
1.6 DOHC	6/90-10/97	AK	1815	AK	T.B.A.
1.6 DOHC	6/90-10/97	AK	T.B.A.	AK	T.B.A.
1.8 Type-R (DC2)	11/97-10/01	AK	2279	AK	2291
2.0 Type-R (DC5)	11/01-	BR	0899	AK	2291
<b>Jazz</b>					
1.2	1/84-9/86	AK	T.B.A.	SU	Drums
1.2	10/01-	SU	1816P	MA	Drums
1.4	3/02-	SU	T.B.A.	AK	2291
<b>Legend</b>					
2.0	4/87-3/91	AK	1470	AK	1485
2.0	4/87-3/91	LU	1497	LU	1498
2.0	4/87-3/91	LU	1499	LU	1498
2.5	4/87-3/91	AK	1470	AK	2291
2.5	4/87-3/91	LU	1497	LU	1498
2.5	4/87-3/91	LU	1499	LU	1498
2.5	4/87-3/91	AK	1470	AK	2291
2.5	4/87-3/91	LU	1497	LU	1498
2.5	4/87-3/91	LU	1499	LU	1498
2.7	4/87-3/91	AK	1470	AK	2291
2.7	4/87-3/91	LU	1499	LU	1498
2.7 Coupè	4/87-3/91	AK	1815	AK	2291
2.7 Coupè	4/87-3/91	AK	1470	AK	2291
3.2 V6	4/91-12/95	AK	2279	AK	2291
3.5	1/96-12/97	AK	2279	AK	2291
3.5	1/98-12/98	AK	2279	AK	2291
3.5	1/99-	AK	T.B.A.	AK	2291
<b>Logo</b>					
1.3	2/99-3/02	SU	1816P	AK	Drums
<b>NSX</b>					
3.0 V6 (NA115)	9/90-12/96	AK	2279	AK	2283
3.0 V6 (NA126)	9/90-12/96	AK	2279	AK	2283
3.0 V6 VTEC (ALB)	1/92-12/96	AK	2279	AK	2283
<b>Prelude</b>					
1.8 (AAB)	2/83-84	AK	1526	AK	T.B.A.
1.8 (AAB)	85-9/87	AK	T.B.A.	AK	T.B.A.
2.0 (BA4)	1/88-12/89	AK	1815	AK	1572
2.0 (BA4)	1/90-8/91	AK	1653	AK	1572
2.0 (BB3)	9/91-12/96	AK	1653	AK	2291
2.0 (BB9)	1/97-10/00	AK	1653	AK	2291
2.0 4WS (BA4)	1/88-12/89	AK	1815	AK	1572
2.0 4WS (BA4)	1/90-10/00	AK	1653	AK	1572

2.0 (BA)	1/88-12/88	AK	1470	AK	1572
2.0 (BA)	1/88-12/88	AK	1815	AK	1572
2.2 4WS (BB1)	1/93-12/96	AK	1653	AK	2291
2.2 VTi-VTi 4WS (BB6/8)	1/97-10/00	AK	2279	AK	2291
2.3 (BB2/3)	9/91-12/96	AK	2279	AK	2291
<b>S2000</b>					
2.0	3/99-	AK	2290	AK	2291
<b>Shuttle</b>					
2.2 (RA1)	2/95-12/97	AK	2279	AK	2291
2.3 (RA3)	1/98-10/00	AK	2279	AK	2291
<b>Stream</b>					
1.7	3/01-	SU	T.B.A.	AK	2291
1.7	6/01-	SU	T.B.A.	AK	2291
2.0	3/01-	SU	T.B.A.	AK	2291
2.0	6/01-	SU	T.B.A.	AK	2291
<b>Vigor</b>					
2.0 20V (CC2)	93-	AK	2279	AK	2291
2.5 20V (CC2)	93-	AK	2279	AK	2291