

<b>LANCIA</b>			<b>ant/front</b>		<b>post/rear</b>
<b>Beta</b>					
(all models)	73-85	BE	0075	BE	0074
Coupe' (all models)	74-85	BE	0075	BE	0074
HPE (all models)	75-85	BE	0075	BE	0074
2.0 Montecarlo	75-83	BE	0027	BE	0026
<b>Dedra</b>					
1.6 iE	9/89-2/93	LU	0268	BE	Drums
1.6 iE	7/91-2/97	LU	0177	BE	Drums
1.6 iE (ABS)	9/89-2/97	LU	0177	LU	0277
1.6 iE	3/97-9/99	AT	0730	LU	0277
1.8 iE (ABS)	9/89-6/96	LU	0177	LU	0277
1.8 iE 16V	7/96-8/97	AT	0731	LU	0277
1.8 IE LX	3/96-9/99	LU	0279	LU	0277
1.9 Turbo Diesel	9/89-12/97	LU	0177	LU	0277
1.9 Turbo Diesel	1/98-9/99	AT	0731	LU	0277
2.0 iE	9/89-6/94	LU	0177	LU	0277
2.0 iE	4/94-6/95	LU	0279	LU	0277
2.0 iE	7/94-8/97	LU	0177	LU	0277
2.0 Turbo iE	4/90-6/94	LU	0279	LU	0277
2.0 HF Turbo iE	4/90-6/94	LU	0279	LU	0277
2.0 Integrale iE-Turbo iE	9/89-6/94	LU	0279	LU	0277
2.0 Integrale	7/94-6/95	LU	0279	LU	0277
2.0 Integrale	7/95-2/96	AT	0732	LU	0277
<b>Delta I</b>					
1.6 HF	79-12/88	LU	0177	BE	T.B.A
1.6 HF	1/89-10/93	LU	0177	BE	0280
1.9 Turbo Diesel	79-10/93	LU	0177	FI	Drums
2.0 HF 4WD	79-12/88	LU	T.B.A	BE	T.B.A
2.0 HF 4WD	1/89-10/93	LU	0279	BE	0280
2.0 Integrale 16V	1/89-10/93	LU	0279	BE	0280
2.0 Integrale Evoluzione	9/91-12/94	BR	0331	LU	0332
<b>Delta II</b>					
1.6 iE 16V	6/93-10/96	LU	0177	LU	0277
1.6 iE 16V	11/96-5/00	AT	0730	LU	0277
1.8 iE 16V	6/93-10/96	LU	0177	LU	0277
1.8 iE 16V	11/96-9/97	AT	0732	LU	0277
1.8 iE 16V	10/97-5/00	AT	0732	LU	0277
1.9 Turbo Diesel	6/93-12/95	LU	0177	LU	0277
1.9 Turbo Diesel	1/96-5/00	AT	0731	LU	0277
2.0 16V	6/93-12/95	LU	0279	LU	0277
2.0 16V	1/96-5/00	AT	0732	LU	0277
2.0 16v HF Turbo	6/93-12/95	LU	0279	LU	0277
2.0 16v HF Turbo	1/96-5/00	AT	0732	LU	0277
<b>Flaminia</b>					
(all models)	61-70	DU	0030	DU	0030
<b>Flavia</b>					
(all models)	63-69	DU	0030	DU	0030
(all models)	70-75	LU	T.B.A	LU	0028
<b>Fulvia</b>					
(all models)	63-69	DU	0030	DU	0030

(all models)	70-76	LU	T.B.A	LU	0028
<b>K</b>					
2.0 20V	10/94-5/98	LU	T.B.A	LU	0775
2.0 20V	6/98-12/01	AT	0732	LU	0775
2.0 16V Turbo	3/96-6/98	LU	T.B.A	LU	0775
2.0 20V Turbo	7/98-12/01	BR	2603A	LU	0775
2.4 20V	10/94-5/98	LU	T.B.A	LU	0775
2.4 20V	7/98-12/01	AT	0732	LU	0775
2.4 JTD	10/94-6/96	LU	T.B.A	LU	0775
2.4 JTD	10/94-6/98	AT	0732	LU	0775
2.4 JTD	7/98-12/01	AT	0732	LU	0775
3.0 V6 24V	10/94-5/98	LU	T.B.A	LU	0775
3.0 V6 24V	7/98-12/01	BR	2603A	LU	0775
<b>Lybra</b>					
1.8	7/99-	AT	0732	LU	0776
1.9 JTD	7/99-	AT	0732	LU	0776
2.0	7/99-	AT	0732	LU	0776
2.4 JTD	7/99-	AT	0732	LU	0776
<b>Musa</b>					
1.3 MJ	10/04-	BO	6756A	LK	Drums
1.4	10/04-	BO	6756A	LK	Drums
1.9 MJ	10/04-	BO	6774SF	LK	Drums
<b>Phedra</b>					
2.0	9/02-	LU	0329	LU	0305
2.2 JTD	9/02-	LU	0329	LU	0305
3.0 V6	9/02-	LU	0329	LU	0305
<b>Prisma</b>					
1.6	3/83-2/84	LU	T.B.A	BE	T.B.A
1.6	6/84-6/89	LU	0177	BE	T.B.A
2.0 4WD	1/87-6/89	LU	T.B.A	BE	T.B.A
2.0 Diesel	3/83-2/84	LU	T.B.A	FI	Drums
2.0 Diesel	6/84-6/89	LU	T.B.A	FI	Drums
2.0 Turbo Diesel	6/85-6/89	LU	T.B.A	FI	Drums
<b>Thema</b>					
2.0 iE	9/84-11/88	LU	0266	BE	T.B.A
2.0 iE	1/89-12/94	LU	0284	BE	0280
2.0 iE	1/89-12/94	LU	0284	LU	0214
2.0 iE Turbo	9/84-11/88	LU	0266	BE	T.B.A
2.0 iE Turbo	1/89-12/94	LU	0284	BE	0280
2.0 iE Turbo	1/89-12/94	LU	0279	LU	0214
2.5 Turbo Diesel	9/84-11/88	LU	0266	BE	T.B.A
2.5 Turbo Diesel	1/89-12/94	LU	0284	BE	0280
2.5 Turbo Diesel	1/89-12/94	LU	0279	LU	0214
2.8 V6	9/84-11/88	LU	0266	BE	T.B.A
2.8 V6	1/89-12/94	LU	0284	BE	0280
2.8 V6	1/89-12/94	LU	0279	LU	0214
3.0 8.32	3/87-12/88	LU	T.B.A	LU	0214
3.0 8.32	1/89-12/94	LU	0279	LU	0214
<b>Thesis</b>					
2.0 Turbo	4/02-	LU	T.B.A	LU	0159
2.4	4/02-	LU	T.B.A	LU	0159

2.4 JTD	4/02-	LU	T.B.A	LU	0159
3.0 V6	4/02-	LU	T.B.A	LU	0159
<b>Trevi</b>					
Trevi (all models)	4/82-7/85	BE	0075	BE	0074
<b>Y</b>					
1.2	1/96-	BE	1941	LK	Drums
1.2 ECVT	1/96-	BE	1941	LK	Drums
1.2 16v	1/97-	AT	0830	LK	Drums
1.4 12v	1/96-	LU	0177	LK	Drums
<b>Ypsilon</b>					
1.2	10/03-	LU	0733	BO	Drums
1.3 JTD	10/03-	LU	0733	BO	Drums
1.4	10/03-	LU	0733	BO	Drums
<b>Z</b>					
2.0 Turbo	6/94-9/02	LU	0738	BE	Drums
2.0 Turbo (ABS)	6/94-9/02	LU	0738	AT	0299
2.1 TD 12V	6/94-9/02	LU	0738	BE	Drums
2.1 TD 12V (ABS)	6/94-9/02	LU	0738	AT	0299