

ROVER			ant/front		post/rear
<b>25</b>					
1.4	10/99-	LU	1675	LU	Drums
1.6	10/99-	LU	1675	LU	Drums
1.8	10/99-	LU	1675	LU	Drums
1.8 GTi Vi	2/00-	LU	1675	AK	1572
2.0	10/99-	LU	1675	LU	Drums
<b>45</b>					
1.4	2/00-	LU	1675	LU	Drums
1.4	2/00-	LU	1675	AK	1572
1.6	2/00-	LU	1675	LU	Drums
1.6	2/00-	LU	1675	AK	1572
1.8	2/00-	LU	1675	LU	Drums
1.8	2/00-	LU	1675	AK	1572
1.8 (146HP)	1/01-	SU	0398	AK	2291
2.0	2/00-	LU	1675	LU	Drums
2.0	2/00-	LU	1675	AK	1572
<b>75</b>					
1.8	2/99-	AT	1673	AT	0299
2.0	2/99-	AT	1673	AT	0299
2.5	2/99-	AT	1673	AT	0299
<b>100</b>					
1.1	5/90-4/99	LU	1674	LK	Drums
1.4	5/90-4/99	LU	1674	LK	Drums
1.4 16V	5/90-4/99	LU	1674	LK	Drums
1.5 Diesel	1/95-10/98	LU	1674	LK	Drums
<b>200 I</b>					
1.3	6/84-10/89	SU	1674	AK	Drums
1.6	6/84-10/89	SU	1674	AK	Drums
<b>200 II</b>					
1.4	10/89-10/95	LU	1660	LU	Drums
1.4 (ABS)	10/89-10/95	LU	1660	AK	1572
1.6 (112HP)	4/90-4/95	LU	1660	LU	Drums
1.6 (112HP) (ABS)	4/90-4/95	LU	1660	AK	1572
1.6 (116HP)	10/92-10/95	LU	1675	LU	Drums
1.6 (116HP) (ABS)	10/92-10/95	LU	1675	AK	1572
1.8 Diesel	10/89-10/95	LU	1660	LU	Drums
1.8 Diesel (ABS)	10/89-10/95	LU	1660	AK	1572
1.8 TD	10/92-10/95	LU	1675	LU	Drums
1.8 TD (ABS)	10/92-10/95	LU	1675	AK	1572
2.0	9/91-10/95	LU	1675	AK	1572
2.0 Turbo	9/91-10/95	LU	1675	AK	1572
<b>200 III</b>					
1.1	11/95-3/00	LU	1675	LU	Drums
1.1 (ABS)	11/95-3/00	LU	T.B.A	AK	1572
1.4	11/95-3/00	LU	1675	LU	Drums
1.4 (ABS)	11/95-3/00	LU	T.B.A	AK	1572
1.6	11/95-3/00	LU	1675	LU	Drums
1.6 (ABS)	11/95-3/00	LU	T.B.A	AK	1572
1.8 Vi	11/95-3/00	LU	1675	LU	Drums
1.8 Vi (ABS)	11/95-3/00	LU	T.B.A	AK	1572

2.0 Diesel	11/95-3/00	LU	1675	LU	Drums
2.0 Diesel (ABS)	11/95-3/00	LU	T.B.A	AK	1572
<b>400 I</b>					
1.4	4/90-4/95	LU	1660	LU	Drums
1.4 (ABS)	4/90-4/95	LU	1660	AK	1572
1.6 (112HP)	4/90-4/95	LU	1660	LU	Drums
1.6 (112HP) (ABS)	4/90-4/95	LU	1660	AK	1572
1.6 (116HP)	4/90-4/95	LU	1675	LU	Drums
1.6 (116HP) (ABS)	4/90-4/95	LU	1675	AK	1572
1.8 Diesel	4/90-4/95	LU	1660	LU	Drums
1.8 Diesel (ABS)	4/90-4/95	LU	1675	AK	1572
1.8 TD	4/90-4/95	LU	1675	LU	Drums
1.8 TD (ABS)	4/90-4/95	LU	1675	AK	1572
2.0	10/91-4/95	LU	1675	AK	1572
2.0 Turbo	10/91-4/95	LU	1675	AK	1572
<b>400 II</b>					
1.4	5/95-3/00	LU	1675	LU	Drums
1.4 (ABS)	5/95-3/00	LU	T.B.A	AK	1572
1.6	5/95-3/00	LU	1675	LU	Drums
1.6 (ABS)	5/95-3/00	LU	T.B.A	AK	1572
1.8	3/96-12/99	LU	1675	AK	1572
2.0 Diesel	5/95-3/00	LU	1675	LU	Drums
2.0 Diesel (ABS)	5/95-3/00	LU	T.B.A	AK	1572
<b>600</b>					
1.8	10/94-2/96	AK	1653	AK	2291
1.9	3/96-6/99	AK	1653	AK	2291
2.0	9/93-2/96	AK	1653	AK	2291
2.0 Di	5/94-2/96-	AK	1653	AK	2291
2.0 Di	3/96-6/99	AK	1653	AK	2291
2.0 SDi	9/93-2/96	AK	2279	AK	2291
2.0 SDi-SLDi	3/96-6/99	AK	2279	AK	2291
2.0 GSi-SLi-Turbo Ti	9/93-2/96	AK	2279	AK	2291
2.0 GSi-Si Lux-SLi-Ti	3/96-6/99	AK	2279	AK	2291
2.0 Si	9/93-2/96	AK	1653	AK	2291
2.0 Si	3/96-6/99	AK	2279	AK	2291
2.3 Si-GSi	9/93-2/96	AK	1653	AK	2291
2.3 GSi	3/96-6/99	AK	2279	AK	2291
<b>800</b>					
2.0	7/86-9/87	AK	1470	AK	1485
2.0	9/87-10/91	LU	1497	LU	1498
2.0	11/91-12/92	LU	T.B.A	LU	0395
2.0	1/93-10/98	LU	1675	LU	0395
2.0 Turbo	8/88-10/91	LU	1497	LU	1498
2.0 Turbo	11/91-12/92	LU	T.B.A	LU	0395
2.0 Turbo	1/93-10/98	LU	1675	LU	0395
2.5 Diesel	10/90-9/91	LU	1497	LU	1498
2.5 Diesel	3/87-2/92	LU	1499	LU	1498
2.5 Diesel	3/87-2/92	AK	1470	AK	1485
2.5 Turbo Diesel	6/90-10/91	LU	1499	LU	1498
2.5 Turbo Diesel	11/91-12/92	LU	T.B.A	LU	0395
2.5 Turbo Diesel	1/93-10/98	LU	1675	LU	0395

2.5	3/87-2/92	LU	1499	LU	1498
2.5	3/87-2/92	AK	1470	AK	1485
2.7 V6	3/87-10/91	LU	1499	AK	1485
2.7 V6	11/91-12/92	LU	T.B.A	LU	0395
2.7 V6	1/93-1/96	LU	1675	LU	0395
<b>1100</b>					
1.1	63-67	LK	0043	LK	Drums
1.1	67-74	LK	0130	LK	Drums
1.3	62-67	LK	0043	LK	Drums
1.3	67-74	LK	0130	LK	Drums
1300GT	71-74	LK	0130	LK	Drums
<b>1800</b>					
1.8	68-72	LU	0053	LU	Drums
1.8	68-72	LU	12-0052	LU	Drums
1.8	72-75	LU	12-0061	LU	Drums
<b>2200</b>					
2.2	69-2/75	LU	12-0052	LU	Drums
<b>Allegro</b>					
1.0	80-1/83	LU	0029	LU	Drums
1.1	1/73-80	LU	0029	LU	Drums
1.3	1/73-1/83	LU	0029	LU	Drums
1.5	1/73-1/83	LU	0029	LU	Drums
<b>Ambassador</b>					
1.7	5/82-12/84	LK	0131	LU	Drums
2.0	5/82-12/84	LK	0131	LU	Drums
<b>Ital</b>					
1.3	80-5/84	LU	0029	LU	Drums
1.7	80-5/84	LU	0029	LU	Drums
2.0	80-5/84	LU	0029	LU	Drums
<b>Maestro</b>					
1.3	10/83-10/92	LU	0212	LU	Drums
1.6	10/83-10/92	LU	0212	LU	Drums
2.0 MG	1/86-10/92	LU	0212	LU	Drums
2.0 M.G Turbo	1/86-10/92	LU	0212	LU	Drums
2.0 Turbodiesel	1/86-10/92	LU	0212	LU	Drums
<b>Marina</b>					
1.3	1/76-8/81	LU	0029	LU	Drums
1.7	1/76-8/81	LU	0029	LU	Drums
1.8	1/76-8/81	LU	0029	LU	Drums
<b>Maxi</b>					
1.5	1/70-12/80	LU	0029	LU	Drums
1750	1/70-12/80	LU	0029	LU	Drums
<b>Metro</b>					
1.0	3/81-10/90	LU	0190	LK	Drums
1.1	5/90-4/99	LU	1674	LK	Drums
1.3	3/81-10/90	LU	0190	LK	Drums
1.3 MG	3/81-10/90	LU	0190	LK	Drums
1.3 MG Turbo	3/81-10/90	LU	0190	LK	Drums
1.4	5/90-4/99	LU	1674	LK	Drums
1.4 16V	5/90-4/99	LU	1674	LK	Drums
1.5 Diesel	1/95-10/98	LU	1674	LK	Drums
<b>MGB</b>					

1.8	62-80	LK	12-0033	LK	Drums
3.5 V8	73-80	LK	0085	LK	Drums
<b>MGC</b>					
3.0	67-69	LU	0053	LU	Drums
<b>MGF</b>					
1.8 16V	10/95-3/02	LU	1674	LU	0395
1.8 16V VVC	9/95-9/01	LU	1674	LU	0395
<b>MGTF</b>					
1.6 115	3/02-	LK	0396	LU	0395
1.8 120-135-160	3/02-	LK	0396	LU	0395
<b>MG ZR</b>					
1.4 105	6/01-	LU	1675	AK	1572
1.6 120	6/01-	LU	1675	AK	1572
1.8 160	6/01-	LU	1675	AK	1572
2.0 Turbodiesel	6/01-	LU	1675	AK	1572
<b>MG ZS</b>					
1.8 120	7/01-	LU	1675	AK	1572
2.5 180	7/01-	LU	1675	AK	1572
<b>MG ZT</b>					
2.5 160-190	6/01-	AT	1673	AT	0299
<b>MG Midget/A-H Sprite</b>					
948	63-72	LK	0043	LK	Drums
1275	63-75	LK	0043	LK	Drums
1.5	75-12/80	LK	12-0033	LK	Drums
<b>Mini</b>					
1.0	84-93	LK	0043	LK	Drums
1.3	93-00	LK	0043	LK	Drums
1.3 Cooper	90-00	LK	0043	LK	Drums
1.3 ERA Turbo	89-90	LU	0190	LK	Drums
1275GT	9/69-9/74	LK	0043	LK	Drums
1275GT	10/74-11/80	LK	0043	LK	Drums
Cooper 998	62-9/69	LK	12-0059	LK	Drums
Cooper S	63-72	LK	0045	LK	Drums
<b>Montego</b>					
1.3	4/84-12/90	LU	0212	LU	Drums
1.6	4/84-9/92	LU	0212	LU	Drums
2.0	4/84-9/92	LU	0212	LU	Drums
2.0 MG	1/86-10/92	LU	0212	LU	Drums
2.0 M.G Turbo	1/86-10/92	LU	0212	LU	Drums
2.0 Turbodiesel	1/86-10/92	LU	0212	LU	Drums
<b>Princess</b>					
1.7	9/78-5/82	LK	0221	LU	Drums
1.8	2/74-6/78	LK	0221	LU	Drums
2.0	9/78-5/82	LK	0221	LU	Drums
2.2	2/74-5/82	LK	0221	LU	Drums
<b>P6</b>					
2.0	6/66-9/66	DU	0030	DU	0030
2.0	10/66-10/73	LU	0053	LU	T.B.A
3.5 V8	2/70-3/76	LU	T.B.A	LU	T.B.A
<b>SD1</b>					
2.0	1/82-9/83	LK	0085	LU	Drums
2.0	10/83-12/87	LK	0095S	LU	Drums

2.3	4/77-9/83	LK	0085	LU	Drums
2.3	10/83-12/87	LK	0095S	LU	Drums
2.4 Diesel	1/82-5/84	LK	0085	LU	Drums
2.4 Diesel	6/84-12/87	LK	0095S	LU	Drums
2.6	4/77-9/83	LK	0085	LU	Drums
2.6	10/83-12/87	LK	0095S	LU	Drums
3.5 V8	4/76-9/83	LK	0085	LU	Drums
3.5 V8	10/83-12/86	LK	0095S	LU	Drums