

SEAT			ant/front		post/rear
124					
all models	4/74-10/80	BE	0027	BE	0026
127					
0.9	4/70-12/86	BE	0027	FI	Drums
0.9 C-CL	11/79-12/86	LU	0148	FI	Drums
1.0	1/81-12/86	BE	0027	FI	Drums
128					
all models	8/78-9/81	BE	0027	FI	Drums
131					
all models	4/75-6/79	BE	0027	BE	Drums
all models	7/79-8/82	BE	0027	BE	Drums
all models	9/82-8/83	BE	0176	BE	Drums
132					
1.6	10/72-2/79	BE	0027	BE	0026
2.0	8/79-9/81	BE	0027	BE	0026
133					
0.7	4/71-1/84	BE	0027	FI	Drums
Alhambra					
1.8 (15" wheels)	3/96-7/00	AT	0459	LU	0305
1.8 (16" wheels)	3/96-7/00	AT	0457	LU	O470
1.8 (15" wheels)	8/00-	AT	0459	LU	0305A
1.8 (16" wheels)	8/00-	AT	0469	LU	O470
1.9 TDi (15" wheels)	3/96-7/00	AT	0459	LU	0305
1.9 TDi (16" wheels)	3/96-7/00	AT	0457	LU	O470
1.9 TDi (15" wheels)	8/00-	AT	0459	LU	0305A
1.9 TDi (16" wheels)	8/00-	AT	0469	LU	O470
2.0 (15" wheels)	3/96-7/00	AT	0459	LU	0305
2.0 (16" wheels)	3/96-7/00	AT	0457	LU	O470
2.0	8/00-	AT	0459	LU	0305A
2.8 V6	8/00-	AT	0469	LU	O470
Altea					
1.6 (15" wheels)	1/04-	AT	0744-S	LU	0305
1.6 (16" wheels)	1/04-	AT	0471V	LU	0305
1.9 TDi (16" wheels)	1/04-	AT	0744-S	LU	0305
1.9 TDi (17" wheels)	1/04-	AT	0471V	LU	0305
2.0 FSi	1/04-	AT	0471V	LU	0305
2.0 TFSi	1/06-	AT	0471V	LU	0305
2.0 TDi	1/04-	AT	0471V	LU	0305
2.0 TDi FR	1/06-	AT	0471V	LU	0305
Arosa					
1.0	5/97-12/99	KH	0742	VG	Drums
1.4	5/97-12/99	KH	0742	VG	Drums
1.4	1/00-	KH	0741	VG	Drums
1.4 16v	1/00-	KH	0741	LU	0305
1.7 Diesel	5/97-12/99	KH	0742	VG	Drums
Cordoba					
1.0	7/97-4/99	KH	0206	VG	Drums
1.0	5/99-9/02	KH	0743	VG	Drums
1.0 (ABS)	5/99-9/02	KH	0743	LU	0305
1.4	11/93-12/95	KH	0215	VG	Drums

1.4	1/96-4/99	KH	0206	VG	Drums
1.4	5/99-9/02	KH	0743	VG	Drums
1.4	5/99-9/02	LU	0243	VG	Drums
1.6	11/93-5/96	KH	0216	VG	Drums
1.6	6/96-4/99	KH	0741	VG	Drums
1.6	5/99-9/02	LU	0243	VG	Drums
1.6 (ABS)	5/99-9/02	LU	0243	LU	0305
1.8	11/93-12/94	KH	0216	VG	Drums
1.8	1/95-9/95	KH	0206	VG	Drums
1.8	10/95-4/99	KH	0741	VG	Drums
1.8 GTi 16V	2/94-4/99	LU	0243	LU	0305
1.9 Diesel	11/93-12/94	KH	0206	VG	Drums
1.9 Diesel	1/95-9/95	KH	0216	VG	Drums
1.9 Diesel	10/95-5/96	KH	0741	VG	Drums
1.9 SDi	6/96-4/99	KH	0741	VG	Drums
1.9 SDi	5/99-9/02	KH	0743	VG	Drums
1.9 SDi	5/99-9/02	KH	0743	LU	0305
1.9 TD	11/93-12/94	KH	0216	VG	Drums
1.9 TD	1/95-9/95	KH	0206	VG	Drums
1.9 TD	10/95-5/96	KH	0741	VG	Drums
1.9 TDi	6/96-4/99	KH	0741	VG	Drums
1.9 TDi	5/99-9/02	LU	0243	VG	Drums
1.9 TDi (ABS)	5/99-9/02	LU	0243	LU	0305
2.0	10/93-4/99	LU	0243	LU	0305
2.0 GTI	10/93-4/99	LU	0243	LU	0305
<b>Cordoba</b>					
1.4 16v (75HP)	10/02-	KH	744	VG	Drums
1.4 16v (75HP) (ESP)	10/02-	LU	0458A	LU	0305
1.4 16v (100HP)	10/02-	KH	744	LU	0305
1.4 16v (100HP) (ESP)	10/02-	LU	0458A	LU	0305
1.4 TDi (100HP)	10/02-	KH	744	LU	0305
1.4 TDi (100HP) (ESP)	10/02-	LU	0458A	LU	0305
1.9 SDi	10/02-	KH	744	VG	Drums
1.9 SDi (ESP)	10/02-	LU	0458A	LU	0305
1.9 TDi	10/02-	KH	744	LU	0305
1.9 TDi (ESP)	10/02-	LU	0458A	LU	0305
2.0	10/02-	LU	0458A	LU	0305
<b>Ibiza I</b>					
0.9	7/85-1/93	BE	0176	FI	Drums
0.9	7/85-1/93	LU	O200	FI	Drums
1.2	4/84-8/90	BE	0176	FI	Drums
1.2	4/84-8/90	LU	O200	FI	Drums
1.2	9/90-4/93	BE	0176	FI	Drums
1.2	9/90-4/93	LU	O200	FI	Drums
1.5	4/84-8/90	BE	0176	FI	Drums
1.5	4/84-8/90	LU	O200	FI	Drums
1.5	3/89-4/93	BE	0176	FI	Drums
1.5	3/89-4/93	LU	O200	FI	Drums
1.7 Diesel	4/84-1/93	BE	0176	FI	Drums
1.7 Diesel	4/84-1/93	LU	O200	FI	Drums
<b>Ibiza</b>					

1.0	5/93-6/96	KH	0215	VG	Drums
1.0	7/96-4/99	KH	0206	VG	Drums
1.0	5/99-2/02	KH	0743	VG	Drums
1.3	5/93-6/96	KH	0215	VG	Drums
1.4	5/93-12/95	KH	0215	VG	Drums
1.4	1/96-4/99	KH	0206	VG	Drums
1.4	5/99-2/02	KH	0743	VG	Drums
1.6	5/93-9/95	KH	0216	VG	Drums
1.6	10/95-6/96	KH	0741	VG	Drums
1.6	7/96-4/99	KH	0741	VG	Drums
1.6	5/99-2/02	KH	0743	VG	Drums
1.6	5/99-2/02	LU	0243	VG	Drums
1.8	5/93-9/95	KH	0206	VG	Drums
1.8	5/93-9/95	KH	0216	VG	Drums
1.8	7/96-4/99	KH	0741	VG	Drums
1.8 GTI	5/93-2/96	LU	0243	LU	0305
1.8 T Cupra	5/99-2/02	LU	0241	LU	0305
1.8 T Cupra R	7/00-9/02	BR	0331B	LU	0305
1.9 Diesel	5/93-9/95	KH	0206	VG	Drums
1.9 Diesel	5/93-9/95	KH	0216	VG	Drums
1.9 Diesel	10/95-6/96	KH	0741	VG	Drums
1.9 SDi	7/96-4/99	KH	0741	VG	Drums
1.9 SDi	5/99-2/02	KH	0743	VG	Drums
1.9 Turbodiesel	5/93-9/95	KH	0206	VG	Drums
1.9 Turbodiesel	5/93-9/95	KH	0216	VG	Drums
1.9 Turbodiesel	10/95-6/96	KH	0741	VG	Drums
1.9 Turbodiesel	7/96-4/99	KH	0741	VG	Drums
1.9 TDi	5/99-2/02	LU	0243	VG	Drums
1.9 TDi (ABS)	5/99-2/02	LU	0243	LU	0305
2.0	5/93-4/99	LU	0243	LU	0305
2.0 GTI	5/93-4/99	LU	0243	LU	0305
<b>Ibiza</b>					
1.2 (14" wheels)	3/02-	KH	0743	VG	Drums
1.2 (15" wheels)	3/02-	LU	0458A	LU	0305A
1.4 16v (75HP) (14" wheels)	3/02-	KH	0743	VG	Drums
1.4 16v (75HP) (15" wheels)	3/02-	LU	0458A	LU	0305A
1.4 16v (100HP) (14" wheels)	3/02-	KH	0744	LU	0305
1.4 16v (100HP) (15" wheels)	3/02-	KH	0744-S	LU	0305A
1.4 16v (100HP) (16" wheels)	3/02-	LU	0458A	LU	0305A
1.4 TDi (14" wheels)	3/02-	KH	0744	LU	0305
1.4 TDi (15" wheels)	3/02-	KH	0744-S	LU	0305A
1.8 T Cupra R	1/04-	BR	0331	LU	0305A
1.8 T FR	1/04-	BR	0331	LU	0305A
1.9 SDi (14" wheels)	3/02-	KH	0743	VG	Drums
1.9 SDi (15" wheels)	3/02-	LU	0458A	LU	0305A
1.9 TDi (14" wheels)	3/02-	KH	0744	LU	0305
1.9 TDi (15" wheels)	3/02-	KH	0744-S	LU	0305A
1.9 TDi (16" wheels)	3/02-	LU	0458A	LU	0305A
1.9 TDi Cupra R	1/04-	BR	0331	LU	0305A
<b>Leon (1M1)</b>					
1.4	11/99-8/05	AT	0744	LU	0305

1.6 (14" wheels)	11/99-8/05	AT	0744	LU	0305
1.6 (15" wheels)	11/99-8/05	AT	0744	LU	0305
1.8 (14" wheels)	11/99-8/05	AT	0744	LU	0305
1.8 (15" wheels)	11/99-8/05	AT	0744	LU	0305
1.8 T Cupra	11/99-8/05	AT	0459	LU	0305
1.8 T Cupra R	2/02-8/05	BR	0331B	LU	0305
1.9 SDi	11/99-8/05	AT	0744	LU	0305
1.9 TDi	11/99-8/05	AT	0744	LU	0305
1.9 TDi (150HP)	2/01-8/05	AT	0459	LU	0305
1.9 TDi (130HP)	5/03-8/05	BR	0331	LU	0305
2.8 V6 Cupra 4	2/01-8/05	AT	0459	LU	0305
<b>Leon (1P1)</b>					
1.4 16v	9/05-	AT	0744-S	LU	0305
1.6 16v	9/05-	AT	0744-S	LU	0305
1.8 20v	9/05-	AT	0744-S	LU	0305
1.9 Tdi (16" wheels)	9/05-	AT	0744-S	LU	0305
1.9 Tdi (17" wheels)	9/05-	AT	0471V	LU	0305
2.0 Fsi (16" wheels)	9/05-	AT	0744-S	LU	0305
2.0 Fsi (17" wheels)	9/05-	AT	0471V	LU	0305
2.0 Tdi	9/05-	AT	0744-S	LU	0305
2.0 TFsi	9/05-	AT	0471V	LU	0305
<b>Malaga</b>					
1.2	6/85-7/92	BE	0176	FI	Drums
1.2	6/85-7/92	LU	0200	FI	Drums
1.5	6/85-7/92	BE	0176	FI	Drums
1.5	6/85-7/92	LU	0200	FI	Drums
1.7 Diesel	6/85-7/92	BE	0176	FI	Drums
1.7 Diesel	6/85-7/92	LU	0200	FI	Drums
<b>Marbella</b>					
0.8	7/86-10/96	BE	0176	FI	Drums
0.8	7/86-10/96	LU	0200	FI	Drums
0.9	7/86-5/99	BE	0176	FI	Drums
0.9	7/86-5/99	LU	0200	FI	Drums
1.3 Diesel	6/89-9/91	BE	0176	FI	Drums
1.3 Diesel	6/89-9/91	LU	0200	FI	Drums
<b>Ronda</b>					
1.2	6/81-12/87	BE	0176	FI	Drums
1.2	6/81-12/87	LU	0200	FI	Drums
1.5	8/83-12/87	BE	0176	FI	Drums
1.5	8/83-12/87	LU	0200	FI	Drums
1.7 Diesel	2/83-4/87	BE	0176	FI	Drums
1.7 Diesel	2/83-4/87	LU	0200	FI	Drums
<b>Toledo I</b>					
1.6	4/91-10/96	KH	0216	VG	Drums
1.6	11/96-3/99	KH	0741	VG	Drums
1.6	11/96-3/99	KH	0743	VG	Drums
1.6 (ABS)	11/96-3/99	LU	0243	LU	0305
1.8	4/91-10/96	KH	0216	VG	Drums
1.8 (ABS)	4/91-10/96	LU	0243	LU	0305
1.8	11/96-3/99	KH	0741	VG	Drums
1.8	11/96-3/99	KH	0743	VG	Drums

1.8 (ABS)	11/96-3/99	LU	0243	LU	0305
1.8 16V GTi	04/91-3/99	LU	0243	LU	0305
1.9 Diesel	4/91-10/96	KH	0216	VG	Drums
1.9 Diesel (ABS)	4/91-10/96	LU	0243	LU	0305
1.9 TD-SDi	11/96-3/99	KH	0741	VG	Drums
1.9 TD-SDi	11/96-3/99	KH	0743	VG	Drums
1.9 TD-SDi	11/96-3/99	LU	0243	LU	0305
1.9 Tdi (110 HP)	04/91-3/99	LU	0243	LU	0305
2.0 16V GTi	4/91-3/99	LU	0243	LU	0305
<b>Toledo II</b>					
1.4 16v	7/99-	AT	0744	LU	0305
1.6 16V (14")	4/99-10/04	AT	0744	LU	0305
1.6 16V (15")	4/99-10/04	AT	0744	LU	0305
1.8 20v	4/99-10/04	AT	0744	LU	0305
1.9 SDi (14")	4/99-10/04	AT	0744	LU	0305
1.9 TDi (14")	4/99-10/04	AT	0744	LU	0305
1.9 TDi (150 HP)	5/01/10/04	AT	0459	LU	0305
2.3 V5 (150 HP)	4/99-5/01	AT	0459	LU	0305
2.3 V5 (170 HP)	5/01-10/04	AT	0459	LU	0305
<b>Toledo III</b>					
1.6	11/04-	AT	0744-S	LU	0305
1.6	11/04-	AT	0471V	LU	0305
1.9 TDi	11/04-	AT	0471V	LU	0305
2.0 FSi	11/04-	AT	0471V	LU	0305
2.0 TDi	11/04-	AT	0471V	LU	0305